



2 Reports

Reports



3 System Setup

System Setup



Manager Mode

Set Up Mode

(Only available if no operator security level set to 2)

1 System Data → 2 Reports → 3 System Setup → 4 Machine Setup → 5 Communications → 6 Data Backup  
(On reverse)


ENTER   ←   →

↓   ↑   ↓

Security can be applied to this menu


4 Machine Setup

Machine Setup




5 Communications



Communication



6 Data Backup


Data Backup





Product Programming

Create & Edit








Change Price

Delete PLU

Copy PLU

Customize Menu



B

A

B

A